

AMULET 6 MEDIA RECORDER

Quick Start Guide




Table of Contents

OVERVIEW

- 2 What's Included
- 4 Front Panel
- 5 Rear Panel


What's Included



Amulet Media Recorder




IR Remote Control*



2 Batteries for Remote Control




HDMI Cable




AC Power Adapter

Amulet — Front Panel



Name		Description
1	Power LED	Solid blue indicates the unit is on Solid red indicates the unit is in standby mode Flashing blue indicates the unit is starting up
2	Network LED	Solid green indicates network is connected
3	Clock	Displays current time set by your service provider. May not display time while device is booting up.
4	Record Indicator	Blue dot indicates a TV program is currently recording
5	HD Indicator	Blue dot indicates current program is playing in HD (720p or higher) resolution

Amulet — Rear Panel



Name		Description
1	A/V OUT	9-Pin DIN connector for connecting to video output using DIN-to-RCA cable
2	Digital Audio	S/PDIF digital optical audio TOSLINK output
3	Reset	Reset the device factory settings with a thin metal probe
4	HDMI	Digital video and audio port for connecting to a high-definition TV (HDTV)
5	IR Extender Jack	To connect IR Extender Receiver
6	USB	To connect USB 3.0 devices such as USB Flash Drive and External Hard Drive (max 900mA load)
7	Ethernet	Plug for wired network connection
8	Power	DC power jack (100-240V, Output 12V/2A)